GATT for all Lansitec devices

https://www.lansitec.com/es/docs/uncategorized/gatt-for-all-lansitec-devices/

NB-IoT

- #define LST_BEACON_UUID_CFG_SERVICE 0xFFF0
- #define LST_BEACON_UUID_LTE_RAT 0xFF01
- #define LST_BEACON_UUID_RAT_SCAN_SEQ 0xFF02
- #define LST_BEACON_UUID_EMTC_BAND 0xFF03
- #define LST_BEACON_UUID_NBIOT_BAND 0xFF04
- #define LST_BEACON_UUID_HOST_NAME 0xFF05
- #define LST_BEACON_UUID_HOST_PORT 0xFF06
- #define LST_BEACON_UUID_MQTT_SSL_SECURE 0xFF07
- #define LST_BEACON_UUID_MQTT_CLIENT_ID 0xFF08
- #define LST_BEACON_UUID_MQTT_USER_NAME 0xFF09
- #define LST_BEACON_UUID_MQTT_USER_PSW 0xFF0A
- #define LST_BEACON_UUID_MQTT_SUB_TOPIC 0xFF0B
- #define LST_BEACON_UUID_MQTT_PUB_TOPIC 0xFF0C
- #define LST_BEACON_UUID_APN_NAME 0xFF0D
- #define LST_BEACON_UUID_APN_USER_NAME 0xFF0E
- #define LST_BEACON_UUID_APN_USER_PSW 0xFF0F
- #define LST_BEACON_UUID_APN_AUTH_METHOD 0xFF10
- #define LST_BEACON_UUID_PARAM_CONFIG_NEW 0xFF11
- #define LST_BEACON_UUID_PARAM_IMEI 0xFF12
- #define LST_BEACON_UUID_PARAM_IMSI 0xFF13
- #define LST_BEACON_UUID_REBOOT_CMD 0xFF14
- #define LST_BEACON_UUID_MSG_LOG_OUTPUT 0xFF15
- #define LST_BEACON_UUID_NET_STATE 0xFF16
- #define LST_BEACON_UUID_DEVICE_RUN_MODE 0xFF17
- #define LST_BEACON_UUID_PARAM_CCID 0xFF18

Cat-1

- #define LST_BEACON_UUID_CFG_SERVICE 0xFFF0
- #define LST_BEACON_UUID_HOST_NAME 0xFF05
- #define LST_BEACON_UUID_HOST_PORT 0xFF06
- #define LST_BEACON_UUID_MQTT_CLIENT_ID 0xFF08
- #define LST_BEACON_UUID_MQTT_USER_NAME 0xFF09
- #define LST_BEACON_UUID_MQTT_USER_PSW 0xFF0A
- #define LST_BEACON_UUID_MQTT_SUB_TOPIC 0xFF0B
- #define LST_BEACON_UUID_MQTT_PUB_TOPIC 0xFF0C
- #define LST_BEACON_UUID_APN_NAME 0xFF0D
- #define LST_BEACON_UUID_APN_USER_NAME 0xFF0E
- #define LST_BEACON_UUID_APN_USER_PSW 0xFF0F
- #define LST_BEACON_UUID_APN_AUTH_METHOD 0xFF10
- #define LST_BEACON_UUID_PARAM_CONFIG_NEW 0xFF11
- #define LST_BEACON_UUID_PARAM_IMEI 0xFF12
- #define LST_BEACON_UUID_PARAM_IMSI 0xFF13
- #define LST_BEACON_UUID_PARAM_CCID 0xFF14
- #define LST_BEACON_UUID_REBOOT_CMD 0xFF15
- #define LST_BEACON_UUID_MSG_LOG_OUTPUT 0xFF16
- #define LST_BEACON_UUID_NET_STATE 0xFF17
- #define LST_BEACON_UUID_DEVICE_RUN_MODE 0xFF18
- #define LST_BEACON_UUID_MODULE_SWITCH_MODE 0xFF19

Beacons

- TBD